

Mercury SmartCraft: Triple Premium installation – C0312

Start Panel

CK01013
Coastkey Start Panel – Mercury ver.
(SW: CKSP_038_MER_EAM_F2M)

CK01020
CoastKey FOB5

Engine #1

CK01511
Engine Box Analog #1+2

Engine #2

CK01518
Engine Box Analog #3

Engine #3

CK20101-0
NWS002-01 Brunswick SmartCraft P&P Harness

CK20101-0
NWS002-01 Brunswick SmartCraft P&P Harness

Same connection as
Engine #1 and #2

Make sure these bullet
connectors are connected if
ignition key switch crank
signal will be used!

Disconnect the Ignition Switch cable
connector from the engine cable connector.
Insert the CoastKey harness as shown.

Female (pins) Male (pins)

Male (pins) Female (pins)

Female (pins) Male (pins)

Male (pins) Female (pins)

Yellow wire from **Engine 1** Harness

White wire from **Engine 1** Harness

Yellow wire from **Engine 2** Harness

White wire from **Engine 2** Harness

UP (Yellow)

DOWN (White)

Yellow wire (UP button) and
White wire (DOWN button).

NOT IN USE

AUX1 and AUX2 Connections			
Wires from Engine harness	FOB Buttons	System	Comments
Yellow wire from Engine Harness 1 (+12V signal)	UP Arrow	Momentary	
Whitw wire from Engine Harness 1 (+12V signal)	DOWN Arrow	Momentary	

Date	Drawn by	Scale
31.03.2025	Pål Sørensen	-

Item name	
C0312 CoastKey Mercury SmartCraft Triple Premium Installation	

Item number	Rev.
NWS021-01-01 (C-Kit: C0312)	A

Wires from Engine harness	FOB Buttons	System	Comments
Yellow wire from Engine Harness 1 (+12V signal)	UP Arrow	Momentary	
Whitw wire from Engine Harness 1 (+12V signal)	DOWN Arrow	Momentary	

Date	Drawn by	Scale
31.03.2025	Pål Sørensen	-
Item name		
C0312 CoastKey Mercury SmartCraft Triple Premium Installation		
Item number		Rev.
NWS021-01-01 (C-Kit: C0312)		A