



Honda iST (DBW): Single Standard installation – C0126



Date	Drawn by	Scale
17.10.2025	Pål Sørensen	-
Item name		
CoastKey Honda iST Installation Single Standard		
Item number		Rev.
NWS021-01-07-02 (C-Kit: C0126)		C

Honda iST (DBW): Twin, Triple and Quad Standard installation – C0226-C0426



This installation will control ignition, and start or stop all engines simultaneously—whether there are two, three, or four engines.

In multi-engine setups, use the Honda start/stop buttons if you need to start or stop engines individually.

Note: Ignition must always be turned on via Coastkey for the Man Overboard function to be enabled.

Date	Drawn by	Scale
17.10.2025	Pål Sørensen	-
Item name		
CoastKey Honda iST Installation Twin, Triple and Quad Standard		
Item number		Rev.
NWS021-01-07-02 (C-Kit: C0226-C0426)		C